





































Original	Replacement	Original	Replacement
Power		Power	Power
Mute		Mute / Dimmer	Mute / Dimmer
Play/Pause		Play / Slow	Play / Slow
I<</Tune-		<< / Tune-	<< / Tune-
>>I/Tune+		>> / Tune+	>> / Tune+
I<</Tune-		I<< / Preset-	I<< / Preset-
>>I/Tune+		>>I / Preset+	>>I / Preset+
Sleep		Sleep / Timer	Sleep / Timer
Setup		Setup / OPT /	Setup / OPT /
Option		Menu / Home	Menu / Home
Up		Up	Up
Info		Info / Angle	Info / Angle
Left		Left	Left
Enter		OK	OK
Right		Right	Right
Down		Down	Down
Back		Back / Return	Back / Return

Original	Replacement	Original	Replacement
Vol+		Vol+	Vol+
Network		Smart / List	Smart / List
CH+		CH+ / Page+	CH+ / Page+
Vol-		Vol-	Vol-
Media Player		Display / Media	Display / Media
CH-		CH- / Page-	CH- / Page-
Tv Audio		1	1
DVD		2	2
CD		3	3
Blu-Ray		4	4
M-XPort		5	5
Tuner		6	6
AUX 1		7	7
iPod/USB		8	8
Internet Radio		9	9
AUX 2		Guide / EPG / -/-	Guide / EPG / -/-
CBL/SAT		0	0





Original	Replacement	Original	Replacement
Power	 Power	Vol-	 Vol-
Mute	 Mute / Dimmer	Media Player	 Display / Media
Play/Pause	 Play / Slow	CH-	 CH- / Page-
I<</Tune-	 << / Tune-	Tv Audio	 1
>>I/Tune+	 >> / Tune+	DVD	 2
I<</Tune-	 I<< / Preset-	CD	 3
>>I/Tune+	 >>I / Preset+	Blu-Ray	 4
Sleep	 Sleep / Timer	M-XPort	 5
Up	 Up	Tuner	 6
Left	 Left	AUX 1	 7
Enter	 OK	iPod/USB	 8
Right	 Right	Internet Radio	 9
Down	 Down	AUX 2	 Guide / EPG / -/--
Back	 Back / Return	CBL/SAT	 0
Vol+	 Vol+	Game	 Fav / Marker / PC
Network	 Smart / List	Favorite Station 1	 Shift + 1
CH+	 CH+ / Page+	Favorite Station 2	 Shift + 2



