



Original	Replacement
Open/Close	Eject / Surround
Standby	Power
Info	Info / Angle
1	1
2	2
3	3
Prog/Direct	TV/Radio /
4	4
5	5
6	6
Clear	Exit / Cancel / Clear
7	7
8	8
9	9
Call	Text / Goto
+10	Guide / EPG / -/--
0	0

Original	Replacement
Search	Red / Netflix / Search
Dimmer	Mute / Dimmer
Input Up AMP	CH+ / Page+
Power AMP	Shift + Power
Mute AMP	Shift + Mute / Dimmer
Vol+ AMP	Vol+
Input Down	CH- / Page-
Vol- AMP	Vol-
Top Menu	D.Menu / Top
Up	Up
PopUp Menu	Smart / List
Left	Left
Enter	OK
Right	Right
Return	Back / Return
Down	Down
Setup	Setup / OPT /





Original	Replacement
Home	Menu / Home
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Play	Play / Slow
I<<	I<< / Preset-
>>I	>>I / Preset+
<<	<< / Tune-
>>	>> / Tune+
Camera/Angle	Shift + Info / Angle
[...] / Subtitle	Subtitle / EQ
O)) / Audio	Audio / Lang I/II
Option	Shift + Setup / OPT / Tools
Repeat	Green / APP / Repeat
Repeat A-B	Yellow / YouTube / Repeat
X/Random	Blue / Prime Video / Random
Pure	Sound / Title
Resolution	Zoom / Size

Original	Replacement
Page/DVD A	AV / Input / RDS
Layer/Disc	Display / Media
ADJ./Picture	Picture / Format
Red	Shift + Red / Netflix /
Green	Shift + Green / APP /
Yellow	Shift + Yellow / YouTube /
Blue	Shift + Blue / Prime
YouTube	Shift + 1
Netflix	Shift + 2
Widi	Shift + 3





Original	Replacement
Open/Close	Eject / Surround
Standby	Power
Info	Info / Angle
1	1
2	2
3	3
Prog/Direct	TV/Radio /
4	4
5	5
6	6
Clear	Exit / Cancel / Clear
7	7
8	8
9	9
Call	Text / Goto
+10	Guide / EPG / ---
0	0

Original	Replacement
Search	Red / Netflix / Search
Dimmer	Mute / Dimmer
Input Up AMP	CH+ / Page+
Power AMP	Shift + Power
Mute AMP	Shift + Mute / Dimmer
Vol+ AMP	Vol+
Input Down	CH- / Page-
Vol- AMP	Vol-
Top Menu	D.Menu / Top
Up	Up
PopUp Menu	Smart / List
Left	Left
Enter	OK
Right	Right
Return	Back / Return
Down	Down
Setup	Setup / OPT /





Original	Replacement
Home	Menu / Home
Stop	Stop / Hold
Pause	Pause / Step / Freeze
Play	Play / Slow
I<<	I<< / Preset-
>>I	>>I / Preset+
<<	<< / Tune-
>>	>> / Tune+
Camera/Angle	Shift + Info / Angle
[...] / Subtitle	Subtitle / EQ
O)) / Audio	Audio / Lang I/II
Option	Shift + Setup / OPT / Tools
Repeat	Green / APP / Repeat
Repeat A-B	Yellow / YouTube / Repeat
X/Random	Blue / Prime Video / Random
Pure	Sound / Title
Resolution	Zoom / Size

Original	Replacement
Page/DVD A	AV / Input / RDS
Layer/Disc	Display / Media
ADJ./Picture	Picture / Format
Red	Shift + Red / Netflix /
Green	Shift + Green / APP /
Yellow	Shift + Yellow / YouTube /
Blue	Shift + Blue / Prime
YouTube	Shift + 1
Netflix	Shift + 2
Widi	Shift + 3

