



Original	Replacement	Original	Replacement
	Open/Close		Eject / Surround
	Power		9
	HDMI Mode		Pict. ADJ.
	Resolution		+10
	Home		0
	Home		Call
	Pure Direct		Clear
	1		Input Up
	2		Power Amp
	3		Mute
	Sound Mode		Vol+
	4		Input Down
	5		Vol-
	6		Top Menu
	Prog Direct		Up
	7		Pop Up Menu
	8		Left
			Enter
			OK
			9
			Picture / Format
			Guide / EPG / -/-
			0
			Fav / Marker / PC
			Exit / Cancel / Clear
			CH+ / Page+
			Shift + Power
			Mute / Dimmer
			Vol+
			CH- / Page-
			Vol-
			D.Menu / Top
			Up
			Menu / Home
			Left
			OK





Original	Replacement
	Right
	Setup / OPT /
	Down
	Back / Return
	+ Shift + Red / Netflix /
	Stop / Hold
	Pause / Step / Freeze
	Play / Slow
	I<< / Preset-
	>>I / Preset+
	<< / Tune-
	>> / Tune+
	Info / Angle
	Subtitle / EQ
	Audio / Lang I/II
	Text / Goto
	Zoom / Size

Original	Replacement
	+ Shift + Green / APP /
	+ Shift + Yellow / YouTube /
	+ Shift + Blue / Prime
	Display / Media
	+ Shift + Mute / Dimmer
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random





Original	Replacement	Original	Replacement
	Open/Close		Eject / Surround
	Power		9
	HDMI Mode		Pict. ADJ.
	Resolution		+10
	Home		0
	Home		Call
	Pure Direct		Clear
	1		Input Up
	2		Power Amp
	3		Mute
	Sound Mode		Vol+
	4		Input Down
	5		Vol-
	6		Top Menu
	Prog Direct		Up
	7		Pop-Up Menu
	8		Left
			Enter
	Eject / Surround		9
	Power		Picture / Format
	Shift + 0		Guide / EPG / -/-
	Shift + Picture / Format		0
	Shift + Menu /		Fav / Marker / PC
	Smart / List		Exit / Cancel / Clear
	Shift + Sound / Title		CH+ / Page+
	1		Shift + Power
	2		Mute / Dimmer
	3		Vol+
	Sound / Title		CH- / Page-
	4		Vol-
	5		D.Menu / Top
	6		Up
	TV/Radio /		Menu / Home
	7		Left
	8		OK





Original	Replacement
	Right
	Setup / OPT /
	Down
	Back / Return
	+ Shift + Red / Netflix /
	Stop / Hold
	Pause / Step / Freeze
	Play / Slow
	I<< / Preset-
	>>I / Preset+
	<< / Tune-
	>> / Tune+
	Info / Angle
	Subtitle / EQ
	Audio / Lang I/II
	Text / Goto
	Zoom / Size

Original	Replacement
	+ Shift + Green / APP /
	+ Shift + Yellow / YouTube /
	+ Shift + Blue / Prime
	Display / Media
	+ Shift + Mute / Dimmer
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random

